




UNIVERSITÀ DI PARMA

Video & Acquisition Systems

- Light
- Acquisition pipeline
- CCD vs CMOS
- Color extraction techniques

Light Spectrum



How do we sense light?



UNIVERSITÀ
DI PARMA



How do we sense light?

UNIVERSITÀ
DI PARMA







- “Two” sensors
- Rods (~100M)
 - More sensitive
 - Mostly distributed on peripheral part of retina
- Cones (~4-7M)
 - “Band pass filters”
 - Different types (typically 3)
 - Mostly around fovea




Fig1b. Scanning electron micrograph of the rods and cones of the primate retina. Image adapted from one by Ralph C. Eagle/Photo Researchers, Inc.








- We need
 - Sensor
 - Transmission
 - Processing
- But this is unfortunately too optimistic!



Actual Acquisition Pipeline





<http://www.dmi.unict.it/~battiato/CVision1011/CVision1011.htm>





■ Charge-Coupled Device:

- ~ Charge is actually transported across the chip and read at one corner of the array and converted (**analog sensor!**)
- ~ Usage of a special manufacturing process to create the ability to transport charge across the chip without distortion.
- ~ Higher Fill Factor

CCD vs CMOS





- Complimentary Metal-Oxide Semiconductor:
 - ~ Several transistors at each pixel amplify and move the charge using more traditional wires
 - ~ It is more flexible because each pixel can be read individually
 - ~ Usage of the same traditional manufacturing processes to make most microprocessors.
 - ~ Easy integration
 - ~ Lower Fill Factor




To compensate for lower fill factor (typically 30-50%), most CMOS sensors use microlenses, individual lenses deposited on the surface of each pixel to focus light on the photosensitive area. Microlenses can boost effective fill factor to approximately 70%, improving sensitivity (but not charge capacity) considerably.

CMOS sensitivity

- Also valid for CCD



Color by separating spectrum





First solution: separate spectrum

Color Field Array

Microlenses to focus spectrum as seen before

Color Field Array is a filter array






Each photoreceptors get a specific color energy

<http://www.dmi.unict.it/~battiato/CVision1011/CVision1011.htm>

- Bayer (RGGB, BGGR, GRBG, GBRG)
- RGB+W (RGB + luminance)
- CYGM
 - Also CMY or CMYW
- RCCC (1 red filter, 3 luminance)
- RCCB
- RGB+NIR

Color Field Array




Real Scene...

...as seen by the sensor.


<http://www.dmi.unict.it/~battiato/CVision1011/CVision1011.htm>

- Simple \rightarrow interpolation is used for averaging color values
- Downsample \rightarrow use a 2×2 block to obtain a RGB pixel
- Edge Sensing \rightarrow “color” edges are used to improve average

Simple Demosaicing




Demosaicing artifacts



(a)




(b)




(a) zipper effects, (b) color shift, (c) aliasing artifacts and (d) blur effects.

Demosaicing

- a) “Grey” levels after color filter array
- b) We can assign a “color” level
- c) Demosaicing
- d) Post Processing



(a)



(b)



(c)



(d)