

LABORATORY #4b


Summary



- Inverse Perspective Mapping (IPM)
- Given an image, project all points on a specific plane



• Given an image point find corresponding world point





- The result can only be a straight line (line of sight)
- It is not possible to invert M


$$p = MP_w \rightarrow P_w = M^{-1} p$$



- In order to invert we can add another constraint
- i.e. P_w belonging to a given world plane

$$\Pi : aX + bY + cZ + d = 0$$







• In such a case we can invert M since basically we add a line obtaining a 4×4 matrix

$$p = \begin{vmatrix} x \\ y \\ z \end{vmatrix} = \begin{vmatrix} M \\ a & b & c & d \end{vmatrix} \begin{vmatrix} X \\ Y \\ Z \\ 1 \end{vmatrix}$$



• The 4×4 matrix can now be inverted

$$P_{w} = \begin{bmatrix} M & & & \\ a & b & c & d \end{bmatrix}^{-1} p$$

Homework



• Given an image and camera parameters use the plane y=0 to reproject pixels



Homework



- Use y=0 plane
 - $(a, b, c, d) \rightarrow (0, 1, 0, 0)$
- Invert M and for each p (u, v) obtain X and Z

$$\begin{bmatrix} X \\ 0 \\ Z \\ W \end{bmatrix} = \begin{bmatrix} m_{11} & m_{12} & m_{13} & r_{14} \\ m_{21} & m_{22} & 23 \\ m_{31} & m_{32} & m_{33} & r_{34} \\ m_{41} & m_{42} & m_{43} & r_{44} \end{bmatrix} \begin{bmatrix} u \\ v \\ 1 \\ 0 \end{bmatrix}$$

$$\begin{bmatrix} X \\ Z \\ W \end{bmatrix} = H \begin{bmatrix} u \\ v \\ 1 \end{bmatrix}$$